

Table of Contents

- RAID 1
- Copy Partition Scheme** 1
- Get Disk Serial 1
- Check RAID Status 1
- Remove a Malfunctioning Disk 1

RAID

Copy Partition Scheme

Save to file

```
sfdisk -d /dev/sda > partitions
```

Restore from File and force

```
sfdisk --force /dev/sda < partitions
```

Get Disk Serial

Using smartctl

```
smartctl -i /dev/sda
```

Check RAID Status

```
cat /proc/mdstat
```

Remove a Malfunctioning Disk

From:
<https://esgr.in/wiki/> - **eSGR Documentation**

Permanent link:
<https://esgr.in/wiki/operations/raid?rev=1513956504>

Last update: **2017/12/22 15:28**



